

## Accessory

### BJ-8-206


| Capacity | Part number       |
|----------|-------------------|
| 0.25-2t  | BJ-8-206-0.25/2t  |
| 500lb-4K | BJ-8-206-500lb/4K |

#### Features:

Easy installation, adjustable height, automatically centralized inside, good ability of anti-side loading. Mainly used for platform scales, floor scales and other electronic weighing devices.



#### Outline Dimension mm(inch)



### BJ-8-207

| Capacity   | Part number       |
|------------|-------------------|
| 0.25t-2t   | BJ-8-207-0.25/2t  |
| 5t         | BJ-8-207-5t       |
| 500lb-4Klb | BJ-8-207-500lb/4K |
| 10K        | BJ-8-207-10K      |

#### Features:

Easy installation, adjustable height, automatically centralized inside, good ability of anti-side loading. Mainly used for platform scales, floor scales and other electronic weighing devices.



#### Outline Dimension mm(inch)

